



Industrial Informatics & Signal Processing Research Group (*iisp*) 1995 -2015

Professor Chris Chatwin

Dr Rupert Young – Reader

Dr Phil Birch – Senior Lecturer

Dr Tai Yang – Reader










Celebrating
50 years
of engineering
at Sussex





24th April 2015

- Research feeds our teaching
- Topics covered
 - Micro and nano manufacture
 - Texrad – medical image processing – spinout
 - Fluorescence microscopy
 - Biometrics
 - Security – target tracking
- Active Topics not covered
 - Healthcare informatics, Big data, Smart cities, Smart grids, Networks, Mathematical Modelling

Research Collaborations and Exchanges with 26 Countries



iisp Graduated 51 Doctoral Students from 27 Countries




- **MSc/ and 4th year MEng, BEng 3rd year: 2015**
 - Cybernetics and Neural Networks; 15 credit course
 - Advanced Manufacturing Technology; 15 credit course
 - Fibre Optic Communications; 15 credit course
 - Satellite & Space Systems; 15 credit course
 - Advanced Digital Signal Processing; 15 credit course
 - Image Processing; 15 credit course
 - Advanced Electronic Systems; 15 credit course
 - Power Systems; 15 credit course
 - Electronics Technology; 15 credit course
 - Computer Networks; 15 credit course

Some statistics

- Grants and contracts \approx £10 million - EPSRC, EU, Industry
- Journal papers: 295
- Books: 2
- Book chapters: 17
- Refereed conference papers: 325
- Professional memberships:
 - IET, IEEE, IOP, OSA, EOP, BCS, ACM, IMechE

Hirsch h-index



Professor Chris Chatwin – h#24

Dr Rupert Young – Reader – h#21


Dr Phil Birch – Senior Lecturer – h#14

Dr Tai Yang – Reader – h#22


The **h-index** is an index that attempts to measure both:

the productivity and citation impact of the published body of work of an engineer, scientist or scholar.


UV Microstereolithography System Diagram 1996 – 2001 EPSRC & EU_{[1], [2]}



Spatial Light Modulator (SLM)



SVGA SLM 800x600 pixels




- Features
- **VGA and SVGA**
- Ultra-II PCI Frame Grab with video and VGA Frame buffers (2Mb each)
- **CCIR/PAL camera**
- Overlay display

Micro-component Prototyping

US

University of Sussex




SLM




Lithographic Lens

Photo-polymer Bath

Microstereolithography System



SVGA SLM 800x600 pixels



UV light path

Main Programme Control Panel

System1.vi *

File Edit Operate Project Windows Help

13pt Application Font

Control Program for the Three Dimension Rapid Prototyping System

Display for System performance

Programmable Stop

STOP

Translation Stage Position

1.15400 mm

Slice Image for Sp...

(640 x 480)

Image Size/Position Control

Ratio of Image Size: 0.30

X-position of Image: 68

Y-position of Image: 293

20

Translation Stage Control using DC Servo

(For a 5µm MOVING STEP)

On Off Zero Stop Moving

Power

Moving Interval: 2000

Distance step: 291.00

Abs Rel Configuration Initialization Status

Actual Position: 0.09500

TargetPosition: 0.09500

Moving Flag: 1

Control for the Image Slices to LCD in SLM

Select_minor: 2

BMP_file Path: file:\shping\bitmaps

bmp format: Not 24bit

Interval Time Control: 2000

BMP File Name: \frameB

Width: 640

Internal timer: 0

IMAGE LAYERS: 20

Height: 480

X: 0

Y: 0

Shutter Control (T132) for Normal Close

Port Number: 0

Action: Write

open duration: 100

close duration: 100

PC: 0 = COM1, 1 = COM2...

Open Shutter (=64 or 40H): @ for ASCII


Close Shutter (=65 or 41H): A for ASCII

Triger Control (=66 or 42H): B for ASCII


Reset Control (=67 or 43H): C for ASCII

Start LabVIEW System1.vi * untitled - Paint Exploring - Proj... Paint Shop Pro ... WinZip (Unregi... System1.vi Dia... Slice Image ... 6:37 PM


MicroSLA System




Micro-components built using 351nm UV




A micro-gear (50
micron layers)




Micro-motor case (50
micron layers)




A helix (50 micron
layers)



Double helix (50
micron layers)





Micro-pyramid (35
micron layers)




Micro-pyramids (50
micron layers)

Micro-fabrication for micro-robots



Gear 50 microns diameter




- A new micro-stereolithography process was developed
- It operates in the UV
- It used an SLM as a dynamic lithographic mask
- We can manufacture micro-parts which are complex in shape that could not be manufactured with either conventional stereolithography or silicon processing methods
- The build time is 30 seconds per layer, with further optimisation this time will be reduced
- Our system is built components with a 5 micron layer thickness

Cell sac, fabricated employing a point-by-point MPP of an organic-inorganic material

US

University of Sussex



Courtesy of Maria Farsari

HOLOGENESIS will pursue vascular regeneration – 2015 EU pending

It will demonstrate the fabrication of a shape-controlled 3D Elastin-like Recombinamers (ELRs) platform that can be tuned to modulate angiogenic paracrine responses of adult stem cells.

Traditional MPP is slow, as it relies on a point-by-point scanning system. Holographic 3D printing will solve this issue; 100nm resolution is possible

Medical Image Processing – TexRAD

Impact Case study – 2008 onwards



University of Sussex



- Research to address the detection of weak structured signals from within highly variable cluttered imagery, originally for vehicle tracking, is being used to identify textural variations in organ tissue. (vehicle tracking later in presentation)
- The technology was spun out into a company, TexRAD Ltd in 2011.
- On Friday 16 May 2014 TexRAD was one of two companies bought by Feedback plc, an AIM-listed company specialising in medical imaging tools.

TexRAD can use existing data

- The TexRAD software has workstation, server and cloud-based versions.
- The clinical evidence generated was sufficient for the first stage of the FDA (USA) and CE (Europe) approvals process ISO-13485 quality and FDA/CE approval expected in 2015.
- TexRAD's texture analysis is a relatively inexpensive and simple process by which tissue abnormalities, and hence prognosis, treatment plans and response to treatment, can be monitored and acted upon without invasive procedures or further images being required.

TexRAD was reversed into Feedback plc

- market capitalization – £3.15 Million



FDBK FEEDBACK PLC ORD 0.25P
FEEDBACK Currency GBX

SUMMARY	INTERACTIVE CHART	PRICES AND TRADES	FUNDAMENTALS	TECHNICAL ANALYSIS	NEWS ANALYSIS	NEWS
---------	-------------------	-------------------	--------------	--------------------	---------------	------

Price	High	Low	Volume	Last close	+/-	Var %
1.65	1.65	1.48	507,896	1.65 on 17-Apr-2015	▲+0.18	+11.86%



As at 19-Apr-2015 19:58:29 - All data delayed by at least 15 minutes.

Bid	1.50
Offer	1.80
Trading status	Market Close
Special conditions	NONE

Learning Centre

Our educational programme aims to provide investors with an understanding of how the products and services offered by LSEG can be used in practice

[find out more](#)

LATEST NEWS

Select source Regulatory

- ◆ Collaboration with the Oxford Stone Group 13 Apr 15
- ◆ Half Yearly Report 13 Feb 15
- ◆ Result of AGM 20 Nov 14
- ◆ Posting of Report & Accounts and Notice of AGM 30 Oct 14
- ◆ Final Results 28 Oct 14

[MORE](#)

COMPANY INFORMATION



Updated Monthly	
Company address	Unit 5, Grange Park, Broadway, Bourn., CB23 2TA, United Kingdom
Company website	http://www.fbk.com
Market cap(in millions)*	£ 3.15

[Listing/Admission](#)

TexRAD Cancer Diagnostics using Biomarkers *iisp* & BSMS, [3], [4]


US

University of Sussex



- LoG Filtered CT Liver Images


TexRAD Launch – 2011



Renal Metastases Demo - Tyrosine Kinase Inhibitors

TexRAD: Potential predictive imaging biomarker of response to treatment in metastatic renal cancer
TexRAD PRE-TREATMENT

Patient undergoing CT




Screenshot of the Renal TexRAD highlighting 'Right lobe liver' metastases (*pre-treatment*) on the conventional CT image (top-left), followed by the derived texture maps superimposed on the conventional CT image – fine (red), medium (green) and coarse (blue) texture

Renal Metastases Demo, [3], [4]


TexRAD: Potential predictive imaging biomarker of response to treatment in metastatic renal cancer

TexRAD POST-TREATMENT



Screenshot of the Renal TexRAD highlighting 'Right lobe liver' metastases (*post-treatment*) on the conventional CT image (top-left), followed by the derived texture maps superimposed on the conventional CT image – fine (red), medium (green) and coarse (blue) texture

Fluorescence Light Sheet Microscope Schematic



Fluorescence Light Sheet Microscope without sample chamber, [5]

US


University of Sussex



Diode Laser

Beam
optics

Illumination
Objective



Sample Chamber
(not shown)


Imaging Objective

Imaging Fluorophores in a Fruit Fly's Heart, [6]



Mobile Iris Biometric ID System

2004- 2005 - industry funding, [7]



Acquire & Convert Iris Biometric into Data

Mobile Iris Biometric ID System, [8]




Scan to Compare Iris Biometric with Remote & Local Database (Iris/Microchip/Datamatrix)

Local
Database

Mobile Iris Biometric ID System



Camera View




Demonstrator
Model


Display

Mobile Iris Biometric ID System

(a) Phone Screen Display





(b) Iris Captured for processing



(a) Screen display of successful Iris capture & processing less than 1 second.


(b) Captured image for processing with grid overlay

Vein pattern recognition hardware



14 Infrared LEDs with 810nm wavelength
USB powered (5V-500mA max)

Finger placed on its dorsal side



CMOS webcam
Infrared (plastic) filter to cut-off visible light

Vein pattern image enhancement



Image without using the infrared pass filter




Image after using the pass filter

Vein pattern recognition software

Captured Image





Image
Resolution
320 x 240

Image Conversion (RGB to
Gray)

Image Enhancement

DoG Filter



Edge Elimination

Processed Image



SDF Filter



Identification

Database Images



Vein pattern recognition software

When the Synthetic Discriminant Function (SDF) filter is applied to the image then the identification process occurs.

Vein pattern not identified
(threshold 0.35)



Vein pattern identified
(threshold 1)



- User selects object
- Algorithms tracks it
- Must cope with
 - Scale
 - Rotation
 - Occlusions
 - Lighting
 - Clutter

- Optimal Trade-off Maximum Amplitude Correlation Height (OT-MACH) filter used as a robust tracker.
- **Scale, Orientation and Velocity invariant robust tracker.**
- Performs in real-time on both colour (visible) and infra-red band scenarios.
- **Conveniently trainable for real-time target tracking applications.**
- Dynamic filter updatability, making the algorithm robust for tracking.

- User interface developed for selecting a target in run-time
- Three types of user selection designed and tested
 - Rectangular
 - Circular
 - Assisted active contour
- Rectangular and Circular target selection found to be less accurate compared to active contour based selection
- The filter function is developed for three different scales of the target after scaling the selected target.

Target selection methods



Rectangular




Circular



Active Contour

Active Contour Target Reference

- Active contour selected target used to create a blank background reference image
- The reference image is rotated -6 to +6 degrees and 7 reference images are created (2 deg increments)
- The reference images are scaled for three different scales and triple filter function bank computed.
- A rotationally multiplexed OT-MACH filter is then created using the reference image sets.



Active contour selected target
reference

Real-time implementation of the OT-MACH tracker ^{,[9]}



University of Sussex




- The filter is automatically updated selecting the current target every update interval set by the end-user (we did this every 25 frames for visible, every 5 frames for IR)
- Rotational multiplexing and triple filter bank increases tolerance of the filter to changes in target orientation and scale changes
- The maximum correlation height values are used to estimate if a filter update is possible or not in the next update interval
- A threshold of 85% of the maximum height value is used to locate the target

Example result and correlation plot

Cross-hair on target



Correlation plot



Kalman filter limitations


- Unlike the OT-MACH tracker, the Kalman filter method is not a suitable estimator for noisy frames, varying velocity targets and extreme scale changes
- A colour based particle filter method was also investigated and compared with the OT-MACH tracker

Kalman filter to distinguish between target and non-targets



Kalman filter(red) and OT-MACH tracker(yellow) result

Colour based Particle filter to distinguish between target and non-targets, [10]



Particle filter(blue particles and red tracking) and OT-MACH tracker(yellow) result

OT-MACH tracker results



Blurred Video of Truck OT - MACH



Gaussian blurring 7x7 kernel, sigma = 2.0

Salt and pepper noise (45% noise) results



A large, semi-transparent orange sphere is centered on the page. It is decorated with several bright, glowing yellow-orange lines that curve across its surface, resembling a stylized globe or a sphere of energy.

Celebrating
50 years
of engineering
at Sussex

1. C Chatwin, M Farsari, S Huang, M Heywood, P Birch, R Young, "UV microstereolithography system that uses spatial light modulator technology," *Applied optics* 37 (32), 7514-7522, 1998
2. CR Chatwin, M Farsari, S Huang, MI Heywood, RCD Young, PM Birch, "Characterisation of epoxy resins for microstereolithographic rapid prototyping," *The International Journal of Advanced Manufacturing Technology*, 15 (4), 281-286, 1999
3. KA Miles, B Ganeshan, MR Griffiths, RCD Young, CR Chatwin, "Colorectal Cancer: Texture Analysis of Portal Phase Hepatic CT Images as a Potential Marker for Survival," *Radiology* 250 (2), 444-452, 2009
4. B Ganeshan, KA Miles, RCD Young, CR Chatwin, "Three-dimensional selective-scale texture analysis of computed tomography pulmonary angiograms," *Investigative radiology* 43 (6), 382-39, 2008
5. PM Birch, R Young, D Budgett, C Chatwin, "Two-pixel computer-generated hologram with a zero-twist nematic liquid-crystal spatial light modulator," *Optics letters* 25 (14), 1013-1015, 2000
6. GD Ward, IA Watson, DES Stewart-Tull, AC Wardlaw, CR Chatwin, "Inactivation of bacteria and yeasts on agar surfaces with high power Nd: YAG laser light," *Letters in applied microbiology* 23 (3), 136-140, 1996
7. LS Jamal-Aldin, RCD Young, CR Chatwin, "Application of nonlinearity to wavelet-transformed images to improve correlation filter performance," *Applied optics* 36 (35), 9212-9224, 1997
8. LS Jamal-Aldin, RCD Young, CR Chatwin, "Synthetic discriminant function filter employing nonlinear space-domain preprocessing on bandpass-filtered images," *Applied optics* 37 (11), 2051-2062, 1998
9. CG Ho, RCD Young, CR Chatwin, "Sensor geometry and sampling methods for space-variant image processing," *Pattern Analysis & Applications*, 5 (4), 369-384, 2002
10. H Waqas, N Bangalore, P Birch, R Young, CH Chatwin, "An Adaptive Sample Count Particle Filter," *Journal of Computer Vision and Image Understanding* 116 (12), 1208-1222, 2012